

STRAIGHTLINE

PERFORMANCE

2010-18 Polaris 600 Y-Pipe
132-111 Ceramic Coated
132-112 High Temp Black Coated

Installation Instructions

1. Remove the existing single pipe from the machine.
2. Remove the bolts from the stock y-pipe.
3. Remove the gaskets from the cylinder and wipe the area clean.
4. Check gaskets, if any wear is prevalent, replace before new SPI y-pipe installation.
5. Install the Straightline Performance Y-pipe in the same order the original parts was removed.
6. Refer to your service manual for torque specifications.

Warranty

Be sure the Straightline y-pipe has no manufacture defects. If the pipe has been run/used there are **no warranties** for fitment.

Specifications

Jetting

Not Required use factory specifications.

Clutching

Not Required use factory specifications.

Straightline Performance 15250 Hornsby St Forest Lake, MN 55025 651-466-0212
www.straightlineperformance.com

Technical questions please email tech@straightlineperformance.com



Facebook @ straightlineperformanceinc

Youtube @ straightlineperfinc

Twitter @ straightlineperf