

# **STRAIGHTLINE**

## **PERFORMANCE**

2015-18 Polaris AXYS 800 HO/Rush/Switchback Y-Pipe

132-121 High Temp Black Coated

### **Installation Instructions**

1. Remove the existing single pipe from the machine.
2. Remove the bolts from the stock y-pipe.
3. Remove the gaskets from the cylinder and wipe the area clean.
4. Check gaskets, if any wear is prevalent, replace before new SPI y-pipe installation.
5. Install the Straightline Performance Y-pipe in the same order the original parts was removed.
6. Refer to your service manual for torque specifications.

### **Warranty**

Be sure the Straightline y-pipe has no manufacture defects. If the pipe has been run/used there are **no warranties** for fitment.

### **Specifications**

#### Jetting

Not Required use factory specifications.

#### Clutching

Not Required use factory specifications.

Straightline Performance 15250 Hornsby St Forest Lake, MN 55025 651-466-0212

[www.straightlineperformance.com](http://www.straightlineperformance.com)

Technical questions please email [tech@straightlineperformance.com](mailto:tech@straightlineperformance.com)



Facebook @ straightlineperformanceinc

Youtube @ straightlineperfinc

Twitter @ straightlineperf