

## Ski-Doo 2004-18 500ss and 600 Y-Pipe 134-132 High Temp Black

## **Installation Instructions**

- 1. Remove the existing single pipe from the machine.
- 2. Use a 6mm ball end hex wrench and 13mm wrench to remove the 8 bolts that retain the y-pipe to the cylinder.
- 3. Remove the gaskets from the cylinder and wipe the area clean. (replace if worn)
- 4. Install the Straightline Performance Y-pipe in the same order the original one was removed.
- 5. Refer to your service manual for torque specifications.

## **Warranty**

Be sure the Straightline y-pipe has no manufacture defects. If the pipe has been run/used there are **no warranties** for fitment.

## **Specifications**

**Jetting:** Not Required use factory specifications. **Clutching:** Not Required use factory specifications.

> Straightline Performance 15250 Hornsby St Forest Lake, MN 55025 651-466-0212 www.straightlineperformance.com

Technical questions please email tech@straightlineperformance.com



Facebook @ straightlineperformanceinc Youtube @ straightlineperfinc Twitter @ straightlineperf