

STRAIGHTLINE

PERFORMANCE

2004-2007 Ski-doo 600/800 Rev Non SDI (134-152)

Installation Instructions

Parts Included

1-Rubber Grommet WS-178

- Remove the stock muffler; this will require the removal of both head springs and the 2 side springs holding the body of the muffler on the sides.
- Install the rubber grommet from the kit over the bottom of the carbon fiber muffler. (this may have been already installed).
- Install the muffler into the stock exhaust hole and spring the inlet onto the stock or SPI muffler using the 2 stock spring
- Install one of the side springs onto the back of the muffler as shown on the picture below.



Make note of spring location on back of muffler.
Be sure that the rubber grommet is in place on the base of the muffler.

Be sure the muffler has no manufacture defects. If the muffler has been run/used there are no warranties for fitment.

- Jetting Requirements- No Jetting Required
- Clutching Requirements-No Clutching Required