

# Ski-Doo 2003-2007 600 H.O. Y-Pipe 134-158 High Temp Black

## **Installation Instructions**

- 1. Remove the existing single pipe from the machine.
- 2. Use a 5mm ball end hex wrench to remove the bolts from the y-pipe.
- 3. Remove the gaskets from the cylinder and wipe the area clean. (replace if worn)
- 4. Install the Straightline Performance Y-pipe in the same order the original parts was removed.
- 5. Refer to your service manual for torque specifications.

### Warranty

Be sure the Straightline y-pipe has no manufacture defects. If the pipe has been run/used there are **no warranties** for fitment.

## **Specifications**

#### **Jetting**

Not Required use factory specifications.

# Clutching

Not Required use factory specifications.

Straightline Performance 15250 Hornsby St Forest Lake, MN 55025 651-466-0212 WWW.straightlineperformance.com

Technical questions please email tech@straightlineperformance.com



Facebook @ straightlineperformanceinc Youtube @ straightlineperfinc Twitter @ straightlineperf