

# STRAIGHTLINE PERFORMANCE

## 2019-20 Ski-doo 900 ACE Turbo Lightweight Muffler Installation Instructions 134-185

1. Remove stock muffler completely. Remove the stock temp sensor and heat shield in order to aid removal. Be sure to not lose any springs or rubber grommets.
2. Install the rubber grommets onto the base of the muffler and top support as shown below.
3. Install the Straightline muffler into the snowmobile and spring the muffler to the downpipe.
4. Install Cone spring and 10mm bolt – **Do not overtighten bolt**





Do not bottom out spring

- **Be sure the muffler has no manufacture defects. If the muffler has been run/used there are no warranties for fitment.**
- Jetting/Fuel Requirements- No Jetting/ Fuel modifications Required
- Clutching Requirements-No Clutching Required

Technical Question Please Email [Tech@straightlineperformance.com](mailto:Tech@straightlineperformance.com)

Bill of Materials (BOM):

Qty	Part Number	Description	In Box
1	134-185	Muffler	
1		Sticker	
1		Instructions	

Checked By:	
-------------	--