

RSI Mountain Grab Bar Mounts installation instructions (Part # HA1002)

If mounting on machine without cross bar using grab bar, please see instructions with mount kit (HA1002).

TOOLS REQUIRED:

12mm wrench

4mm Allen wrench

Step 1: install Jam nuts on grab handle finger tighten until nut is flush with rubber handle (Do not use wrench or over tighten)



Step 2: Install grab bar into Grab Bar mounts spin on until bottomed out and minimal thread is exposed.



Step 3: Remove bottom caps from Grab bar mounts, install grab bar on handlebars. Grab bar mounts can be orientated towards the bar pad or away from bar pad depending on application (see last pictures of instructions). Finger tighten bottom cap of grab bar mounts.

Step 4: Using 12mm Wrench tighten Jam nut on to grab bar mount



Step 5: Align grab bar and tighten bottom caps of grab bar mounts using 4 mm Allen wrench



We love to see your customized sleds Tag us on social media: @rsiracing - you may even win some prizes for tagging/sharing to our pages!

LIMITED WARRANTY

RSI Racing warrants this product to be free from defects in material and workmanship under use for the purpose it was intended.

RSI Racing shall not be liable for damage or injury caused by defective materials or workmanship. **RSI Racing** may elect to repair or replace this product, but RSI Racing is the sole judge of any defects in their product. This warranty does not cover any labor costs to remove or reinstall this product and is effective for one year from the original purchase date.

RSI Racing 15250 Hornsby St Forest Lake, MN 55025 208-994-6413 www.rsiracing.com