



**PLEASE READ ALL INSTRUCTIONS BEFORE INTALLING KIT.**

*WARNING: Before any installation of this RSI product you need to verify your snowmobile is operating and working correctly.*

**INSTRUCTIONS FOR UR-12 AND UR-13  
POLARIS 1/2" AND 3/4" RISER BLOCKS**

1. REMOVE STOCK HANDLEBAR CLAMPS AND BOLTS FROM STEERING POST.
2. INSTALL RSI RISER BLOCKS BETWEEN THE HANDLEBAR CLAMPS AND THE TOP OF THE STEERING POST. USE SUPPLIED BOLTS AND NUTS TO SECURE TO STEERING POST WITH OEM SPECS.



Phone: (208-994-6413)

E-Mail: [customerservice@rsiracing.com](mailto:customerservice@rsiracing.com)

Copyright © 2007-2016 RSI USA All Rights Reserved

Disclaimer:

RSI assumes no liability for mechanical damage, engine damage, personal injury or crash damage of any kind due to improper installation or use of this product. The owner / operator of the snowmobile assumes all liability when using this product on their snowmobile.