







**Straightline Polaris AXYS Rugged Series/ Sport Combined Skid Plate 182-112
(Instructions and BOM)**

Kit includes:

P9	Skid plate		QTY 1
P6	7/8" Bolt		QTY 2
P7	Nylock Nut		QTY 2
P8	Fender Washers		QTY 2

Directions: Refer to Directions on 182-109 This Part is installed at Step 3.

BOM Circle Color:

182-112 182-112-White 182-112-Yellow 182-112-Red 182-112-Orange 182-112-Blue
182-112-Green 182-112- Raw

Quantity	Item #	Descriptions	In Box
1	182-112	Skid Plate	
1	10200-11209	Skid Plate hardware	
1		Straightline Sticker	

Checked and Packaged By

Technical questions please email tech@straightlineperformance.com

Facebook @ straightlineperformanceinc
Youtube @ straightlineperfinc
Twitter @ straightlineperf